


Section 5 PARTS



This drawing and the components list on the following page are representational only. There may be differences between this information and your machine, especially if the X-axis and Z-axis power options are installed.

TABLE, COLUMN & BASE COMPONENTS Fig 1